




## VISIX VX-5M28-MD-IW 5MP Fixed Mini Dome Camera (2.8mm Lens)

## **Quick Start Guide**


Ver. 1.0 / 2020.04

Before installing and using the camera, please read this manual carefully. Be sure to keep it handy for future reference.



- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- areagned to provide reasonable protection against naminal interestence when the equipment is operated in a commencial environment. It is operated, used in a distance and can adulate acid frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmfunterference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the us of required to correct the interference at his own excesses.
- b. This device complies with CAN ICES-3 (A)/NMB-3(A)
- d. This device complies with CE 2014/30/EU = EMC Directive, 2015/863/EU RoHS3 as part of 2011/65/EU RoHS

# Step 1. Product & Accessories






















CAUTION RISK OF FLECTRIC SHOCK DO NOT OPEN



### CALITION

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK) NO USER SERVICEABLE PARTS INSIDE. REEER SERVICING TO OUR USERNICE DERSONNEL

This symbol indicates that dangerous voltage consisting a risk of electric shock is present within this unit.

This exclamation point symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.


## WARNING

To prevent damage which may result in fire or electric shock hazard, do not expose this appliance to rain or

#### WARNING

- 1. Be sure to use only the standard adapter that is specified in the specification sheet. Using any other adapter could cause fire, electrical shock, or damage to the product.
- 2. Incorrectly connecting the power supply or replacing battery may cause explosion, fire, electric shock, or damage to the product.
- 3. Do not connect multiple cameras to a single adapter. Exceeding the capacity may cause abnormal heat generation or fire.
- 4. Securely plug the power cord into the power receptacle. Insecure connection may cause fire.
- 5. When installing the camera, fasten it securely and firmly. A falling camera may cause personal injury.
- 6. Do not place conductive objects (e.g. screw drivers, coins, metal things, etc.) or containers filled with water on top of the camera. Doing so may cause personal injury due to fire, electric shock, or falling

# Step 2. Part Name



## 7. Do not install the unit in humid, dusty, or sooty locations. Doing so may cause fire or electric shock.

- 8. If any unusual smells or smoke come from the unit, stop using the product. In such case, immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock.
- 9. If this product fails to operate normally, contact the nearest service center. Never disassemble or modify this product in any way.
- 10. When cleaning, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock.

#### CAUTION


- 1. Do not drop objects on the product or apply strong shock to it. Keep away from a location subject to excessive vibrationor magnetic interference.
- 2. Do not install in a location subject to high temperature low temperature or high humidity. Doing so may cause fire or electric shock.
- 3. If you want to relocate the already installed product, be sure to turn off the power and then move or
- 4. Remove the power plug from the outlet when then there is a lightning. Neglecting to do so may cause
- 5. Keep out of direct sunlight and heat radiation sources. It may cause fire.
- 6. Install it in a place with good ventilation.
- 7. Avoid aiming the camera directly towards extremely bright objects such as sun, as this may damage the
- 8. Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases. shall be placed on the apparatus.
- 9. The Mains plug is used as a disconnect device and shall stay readily operable at any time.

# Step 3. Disassemble the Camera

## Before installing your camera, you have to read the following cautions.

Reset Buttor

- 1. You have to check whether the location can bear five times of the weight of your camera.
- 2. Do not let allow the cable to be pinched or caught and be sure not to damage electric line. This may lead to fire.
- 3. When installing your camera, do not allow any person to approach the installation site. If you have any valuable things under the install location, move them.





Detach the dome cover using the provided torx

from the bottom case before installation of the

Be sure to align the screw holes properly when you

the setup to the factory default.

## Warning:

If you press the 'Reset' button, you will lose all settings data. If needed, please, make a note for further installation.


2 The camera has a manual IR switch, located under the camera's lens. You can use this switch to manually turn the IR LED board on or off according to the installation requirements.

## **Important Safety Instructions**

## WARNING

- Read these instructions.
- 2. Keep these instructions.
- 3. Heed all warnings.
- 4. Follow all instructions.
- 5. Do not use this apparatus near water.
- 6. Clean only with dry cloth.
- 7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8. Do not install near any heat sources such as radiators, heat registers, or other apparatus (including amplifiers) that produce heat.
- 9. Do not defeat the safety purpose of the polarized or grounding-type plug A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet
- 10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11. Only use attachments/accessories specified by the manufacturer
- 12. Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus.
- 13. Unplug this apparatus when a cart is used. Use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

## Step 4. Installation



- Disassemble the camera. See the Disassemble the camera' section for details.
- 2 Using the template sheet, drill the cabling oles on the wall/ceiling.
- 3 Connect the network cable and power cable respectively. See 'Cabling' for details.
- Put the Lan cable into (a), then (b) will be assembled to (a) tightly. As a final step, (c) need to be assembled to (b) without making any space.




- 4 Affix the bottom case to the ceiling / wall.
- 5 To achieve desired view direction and orientation, rotate the 3-axis gimbal. To fix the setting, tighten the tilt stopper screw.



- 6 Assemble the dome cover to the bottom case.
- Detach the protective film from the dome cover


## Step 5. Installation Using Mount Bolt & Nut



- Disassemble the camera. See the 'Disassemble the camera' section for details.
- 2 Using the template sheet, make the drill the cabling hole on the ceiling panel.



3 Insert the 2 mount bolts into bottom case of



- connecting the cables.
- 6 Fix the camera by tightening mount nuts to mount bolts on the ceiling panel.

Insert the mount bolts into template holes after



6 To achieve desired view direction and orientation, rotate 3-axis gimbal. To fix the setting, tighten the tilt stopper screw.



- Assemble the dome cover to the bottom case
- Operation by Detach the protection film from the dome cover

## Step 6. Cabling

#### Two Options

Use a PoE-enabled switch to connect data and power through a single cable and begin viewing and recording images instantly. A non-PoE switch will require an adaptor for nower transmission

#### 1. Using a PoE-Enabled Switch


The Camera is PoE-compliant, allowing transmission of power and data via a single Ethernet cable.

PoE eliminates the need for the different cables used to power, record, or control the camera. Follow the illustration below to connect the camera to a PoE-enabled switch using an Ethernet cable.




#### 2. Using a Non-PoE Switch

If a PoE-enabled switch is not used, use a power adaptor for power transmission and non-PoE switch for data transmission. Follow the illustrations below to connect the camera without a PoE-enabled Switch. switch using an Ethernet cable.



## Step 7. IP Installer



- Run the 3xLOGIC Camera Setup Utility i. Download and install the latest version of the utility
- at www.3xlogic.com. ii. Navigate to Start > Programs > VIGIL>Utilities and
- launch the VIGIL Firewall Utility. Create a firewall rule for VISIXIPSetup-B Utility if one has not already been created.
- iii. Launch VIGIL Server, navigate to Settings > Cameras.
- iv. Select the desired camera channel from the treeview.
- v. Open Network Camera Settings and set the Type to VISIX-IP-R
- Select the desired camera.

after the utility deploys.

time to identify cameras.

3 The information of the selected camera will be shown in Device Info. vi. Click the Detect Camera button. The utility will now launch.

3 Select the NIC associated with your cameras

hen click on the Search button. Allow the utility

# Step 7 cont'd

- 6 Select the network type.
- 1 The default network type of the camera is DHCP mode
- 1 If you have a DHCP server, it will automati -cally set the Camera IP.
- 1 If you do not have a DHCP server, Camera IP is set to 192.168.1.80 after one minute.
- 1 Input IP settings information when the network changing IP Settings.
- Default TCP/IP information - IP: 192.168.1.80
- Subnet Mask: 255.255.255.0
- Gateway: 192.168.1.1 - DNS: 168.126.63.1
- (3) Change the port as necessary when the network type is set to STATIC.
- A 'Port Forwarding' has to be set for external access to the camera.
- Refer to the manual of the network hub for 'Port Forwarding' settings.
- An additional change of HTTPS, RTSP port can be done at Web Viewer >Admin page.

## Ochange Password.

- 1 Default ID / PW : admin / admin
- The default user ID and password must be changed for security reasons. Video will not stream from the camera until the default admin password is changed. Enter the default credentials (admin / admin) and click Change Password. Enter and confirm a unique password. and click OK to complete the change.
- The ID and PW will be set to default value when a 'factory reset' is perfomred on the camera the camera.
- save changed values
- M An Apply message will deploy when the settings are applied normally, or an error message will deploy if the settings fail to apply. This step saves settings to the camera itself.
- After applying the new camera settings, click Save to VIGIL
- ▼ This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the camera to the VIGIL Server software

  This step saves the vicin saves the VIGIL Server software

  This step saves the vicin saves the VIGIL Server software

  This step saves the vicin saves the VIGIL Server software

  This step saves the vicin saves the VIGIL Server software

  This step saves the vicin saves the VIGIL Server software

  This step saves the vi The camera will occupy the camera channel you selected in Step 1 (iv) of this section.
- Rebooting or Resetting the Camera to Factory Settings

If a factory reset is required, login to the camera's browser interface (enter IP into a browser URL bar and login to the camera) then navigate to Setup > System > Factory Reset. To perform a basic camera retart, Navigate to Setup > System > Restart

# Step 8. Viewing Camera in VIGIL Client

After adding the camera to VIGIL Server, 3xLOGIC recommends VIGIL Client for viewing live and playback. Client's powerful tool set can be leveraged by users to thoroughy and quickly review camera footage and other data collected by a VIGIL Server. After adding a VIGIL Server to VIGIL Client, refer to the steps in this section for details on viewing the camera's footage in VIGIL Server.



1 After launching VIGIL Client, extend the Servers node located in the Sites tab treeview then double-click the desired VIGIL Server to reveal available devices and tools.

2 Expand the Camera node to reveal the VIGIL Server's cameras.

- Double-click the desired camera. The camera's live stream will be automatically displayed in the
- Live Edge Controls instantly grant the user access to common tools such a Capture Still Image, Instant Replay and Stream Type Selection.
- 6 Stream information such as FPS rate, bitrate and CODEC type are listed when the cursor hovers over the bottom edge of the frame.

Select Instant Replay from the Live Edge Controls to open the last 5 minutes of footage from the camera or perform a playback search to review a custom time range of playback. A Playback viewer featuring the requested footage will deploy.



- 1 Playback Left-Edge controls include Export Video or Stills, Stream Mode Selection and Screen Record, etc...
- 2 Right-Edge Controls include more tools such as Smart Search, Audio and Zoom Controls and
- 3 Stream information and standard playback controls are accessible at the bottom of the frame.
- 4 Located next to the scrub bar, footage markers and export tools can be used to quickly narrow down and export portions of interest within larger video clips.

For further details on reviewing and exporting playback and other advanced features such as audio recording and two-way audio talk, POS Data OSD and more, please visist www.3xlogic.com and consult the product documentation library for VIGIL Client-related support documentation.

## **Disposal of Old Appliance**



- . When this crossed-out wheel bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
- 2. All electrical and electronic products should be disposed of separately form the municipal waste stream in accordance to laws designated by the government or the local authorities
- 3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
- 4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

